3D Printing Forum - Kraftwurx - Kraftwürx 3D Printing

Generated: 28 April, 2024, 12:19

						\sim
I)	ım	er	ารเ	\cap	n	ς?

Posted by mash3d - 2013/04/07 20:34

When uploading a model you have the Dimensions settings in the scale box Only problem is there is no indication of which box is Height or Width and depth? Can you tell em which on is which and possibly update the web site to include that information? Also I assume the scale is locked proportionality so that changing one changes all of them? thanks,

Michael

Re:Dimensions?

Posted by Marco CM - 2013/04/08 11:58

Hello Michael,

Currently the 3d model viewer does cannot tell you which way is up or down for your model. This is because each 3d software exports models differently. However we do plan to add a XYZ coordinate marker into the 3d view. This way you can see what axis the dimensions are on. All of the scales are proportionally locked, correct.

-Marco CM
